

# SUZUKI

Vehicle Make	Year Range	Manufacturer of Axle	Axle Model	Spline Count	Cover Bolts	Special Notes	Lock-Right
							Open
<b>Samurai</b>							
Front Axle (see notice at bottom of page)							
1989 - 1995							
1986 - 1988				22	1510		
Rear Axle							
1989 - 1998	SUZUKI	6.9" rg	26	10	See notice #3	1510 or 1530	
<b>Sidekick</b>							
Front Axle (see notice at							
1989 - 1998							
Rear Axle							
1989 - 1995	SUZUKI	6.9" rg	26	10	See notice #3	1512 or 1532	
<b>Vitara</b>							
Front Axle (see notice at bottom of page)							
1999 - 2000							
Rear Axle							
1999 - 2000							
<b>Grand Vitara</b>							
Front Axle (see notice at bottom of page)							
1999 - 2000							
Rear Axle							
1999 - 2000							

## NOTICE REGARDING ACCURACY OF THIS GUIDE:

Powertrax has attempted to make this Application Guide as accurate as possible. However, Powertrax cannot guarantee correctness. Identical model vehicles may have different axles or differentials than stated in this guide depending on original options ordered and other factors. It is advisable to check the vehicle to determine precisely which differential and axle are present. **IF YOU HAVE ANY QUESTIONS, PLEASE DON'T HESITATE TO CONTACT US AT 800-578-1020.**

## NOTICE REGARDING FRONT AXLE APPLICATIONS:

The Powertrax Lock-Right Locker works well on the front axle of 4-wheel drive vehicles provided a couple of important guidelines are followed. The Lock-Right Locker should be used only on vehicles equipped with locking hubs on the front axle or with front axle disconnect. In addition, the vehicle must not be equipped with full time 4-wheel drive. Vehicles equipped with a Lock-Right Locker on the front axle should not be operated on the highway with the front hubs locked and 4-wheel drive engaged. Following these guidelines will ensure very on-road driveability while still providing maximum off-road traction.

## NOTICE REGARDING SUZUKI SIDEGEARS

Lock-Right models #1510 and #1512 are designed to work with the stock sidegears in the vehicle. Powertrax supplies gears that mate with these sidegears. These units work exceptionally well except on vehicles with a high amount of mileage and therefore worn sidegears. Rather than replacing the sidegears with factory gears, simply install Lock-Right model #1530 or #1532. Lock-Right models #1530 and #1532 replace the factory sidegears.